

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Below are the safety warnings for handling batteries.

- Battery insertion must be done by an adult.
- Do not short circuit battery contacts.
- Do not mix old and new batteries.
- Do not mix Alkaline and standard (heavy duty, carbob-zinc) batteries.
- Dispose of batteries safely and correctly.
- Do not attempt to burn batteries. Remove exhausted batteries.
- Remove batteries if product will not be used for a long period.

Note:

You can operate all Mad Dog Motor vehicles simultaneously, make sure you set the vehicle and controller to same number (#1 or #2) to operate.

The radio circuitry in your car and controller is sensitive. Radio interference can affect the control of the vehicle. You may have to choose another location to operate your vehicle.

This equipment has been tested and found to comply with the limits for a Class D digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Toll Free Hot Line: 800-816-1135

WARNING:
CHOKING HAZARD - Small parts
Not for children under 3 years.

Kid Galaxy®
Copyright © 2008 Kid Galaxy, Inc.

INTERACTIVE R/C Demolition Derby Cars


CONTENTS



OPERATING INSTRUCTIONS

Remote Control

1. Unscrew battery cover on bottom of controllers with a Phillips screw driver.
2. Install 3 AAA batteries with polarities as shown inside of battery compartment.
3. Replace battery cover and screw shut.




4. Choose channel #1 or #2 on controller power switch. **(MAKE SURE YOUR CAR IS SET TO THE SAME CHANNEL NUMBER AS CONTROLLER)**



5. EXTEND CONTROLLER ANTENNA FULLY.

Derby Car Vehicles


1. Unscrew battery cover on bottom of car with Phillips screwdriver.
2. Install 2 AAA batteries with polarities as shown in battery box.



OPERATING INSTRUCTIONS CONTINUED

3. Replace battery cover and screw shut.

4. Turn switch on bottom of car to the # 1 or #2 position **(MAKE SURE YOUR CONTROLLER IS SET TO THE SAME CHANNEL NUMBER AS CAR)**




5. PUSH GAS PEDAL FORWARD TO DRIVE CAR FORWARD.

6. PUSH GAS PEDAL BACK TO DRIVE CAR BACK IN REVERSE.

7. PUSH STEERING CONTROL TO RIGHT, CAR DRIVES TO RIGHT.


8. PUSH STEERING CONTROL TO LEFT, CAR DRIVES TO LEFT.




OPERATING INSTRUCTIONS CONTINUED

Drive your Demolition Derby cars over the ramps, crash 'em and smash 'em into the traffic cones and into each other. The body parts will eject!

- A head on collision causes the hood and doors to pop out. **Car will stop operating after doors pop out!**



- A rear ended collision causes the roof and doors to pop out. **Car will stop operating after doors pop out!**



- To reset your Demolition Derby car, simply press roof back into place, then push side doors in and your car is ready to race again!

