




Ratchet Racers


DESCRIPTION



WIND UP AND PLAY!

- 

1 Connect halves together
- 

2 Twist halves as shown. Car is fully wound when "click" is heard!
- 

3 Press "launch" button, car races away!

★ To rewind, depress launch button to reset car

Safety clutch prevents overwinding!

OPERATION TIPS AND HELPFUL HINTS

- Do not allow **Ratchet Racers** to come in contact with water or sand.
- **Ratchet Racers** is NOT intended to be used outdoors.
- Do not attempt to retrieve **Ratchet Racers** if they run underneath furniture. Ask an adult for help to get your cars out safely.

KID GALAXY INC. LIMITED WARRANTY

- Kid Galaxy's products are covered under a 60 day limited warranty against manufacturer's defects. If a product is deemed defective and falls within the 60 day period, Kid Galaxy will repair or replace it at no charge. We require a copy of the original sales receipt to validate the purchase. Product must have been purchased within the US or Canada to be eligible. Please email us at:

customerservice@kidgalaxy.com or call us.

Toll Free Hot Line: 800-816-1135

www.kidgalaxy.com

Kid Galaxy, Inc. 150 Dow St., Ste. 425B, Manchester, NH 03101

Product Manufactured In China

 **WARNING:**
CHOKING HAZARD- Small parts
Not for children under 3 years.

Kid Galaxy®

Copyright © 2011

Kid Galaxy, Inc.